





# **OPERATING MANUAL** FIBARO ROLLER SHUTTER 2 FGR-222-EN-A-v1.00

FIBARO Roller Shutter 2 is a universal, Z-Wave compatible, electric motor controller. The device allows for controlling motors of roller blinds, awnings, venetian blinds, gates and others, which are single phase AC powered. FIBARO Roller Shutter 2 allows for precise positioning is available for the motors equipped with mechanic and electronic end switches.

The module may be controlled wirelessly, through the Z-Wave network main controller, or through the switch keys connected to it. It's also possible to combine few devices into groups of devices, which then can be controlled simultaneously. In addition, FIBARO Roller Shutter 2 is equipped with Power Metering.

#### I. SPECIFICATIONS

ower supply:	110 - 240 V AC
	50 - 60 Hz

to 0.8 W Power consumption:

Operational temperature: 0 - 35°C

Dimensions (L x W x H): 42.5 x 38.25 x 20.3 mm

For installation in hoxes: Ø ≥ 50mm, depth ≥ 60mm

Rated load current:

4,2 A for lamps and resistive loads 1,7 A for motors with compensated power factor (inductive loads)

Active element: micro-gap relay switch u

single-phase AC motors Type of supported motor:

Supported limit switches type: electronic and mechanic

Device control: remotely - radio waves

Radio protocol: 7-Wave

868.4 MHz EU: Radio Frequency:

908.4 MHz US: 921,4 MHz AN7

1mW

Range:


Radio signal power:

up to 50 m outdoors up to 30 m indoors ending on building materials)

869.0 MHz RU:

Comply with EU directives:

RoHS 2011/65/EU LVD 2006/95/EC EMC 2004/108/EC R&TTE 1999/5/FC



# II. TECHNICAL INFORMATION

- Controlled by FIRARO system devices or any Z-Wave controller. · FIBARO Roller Shutter 2 is an extension unit.
- · Microprocessor control.
- · Active element: electromagnetic, micro-gap relay switch.
- · The device may be operated by momentary or toggle switches, and by dedicated roller blind control switches.
- Connected motor's current and historical power consumption measured.
- · To be installed in wall switch boxes of dimensions allowing for installation, conforming to provisions of applicable regulations.

III. SUPPORTED LOADS	
FGR-222	110-240 V~
lamp and resistive load	4,2 A
2 Minductive load	1,7 A

### IV. GENERAL INFORMATION ABOUT FIBARO SYSTEM

EIRARO is a wireless smart home automation system, based on the Z-Wave protocol. All of available devices can be controlled through a computer (PC or Mac), smartphone or tablet. Devices are not only receivers, but can also repeat the signal, increasing the Z-Wave network's range. It gives advantage over traditional wireless systems that require direct link between transmitter and receiver, as a result the construction of the building could affect network's range

Every FIBARO network has its unique identification number (home ID). Multiple independent networks can exist in the building without interfering. Transmission security of FIBARO System is comparable

Z-Wave technology is the leading solution in smart home automation. There is a wide range of Z-Wave devices that are mutually compatible independently of manufacturer. It gives the system the ability to evolve and expand over time. For more

## V. ROLLER SHUTTER INSTALLATION



CALITION

Read this manual before attempting to install the device! Failure to observe recommendations included in this manual may be dangerous or cause a violation of the law. The manufacturer, Fibar Group S.A., will not be held responsible for any loss or damage rasulting from not following the instructions of operating manual.



Electrical system of the building must be protected with an overcurrent protection (fuse) with a value not higher than 10A.



### DANGER

Danger of electrocution! All works on the device may be performed only by a qualified and licensed electrician. Observe national regulations. Faulty connection or use may result in fire or electric



Danger of electrocution! Even when the device is turned off, voltage may be present at its terminals Any works introducing changes into the configuration of connections or the load must be always performed with disconnected voltage (disable the fuse).



### DANGER

nce work on controlled devices may be performed only after the power supply has been



It's not recommended to operate all of the roller blinds simultaneously. For safety reasons, at least one roller blind should be controlled independently, providing safe escape route in case of emergency



Do not connect the device to loads exceeding recommended values. Connect only in accordance with the diagram presented in the manual ns may be dangerous

- 1. Before installation make sure the voltage supply is
- 2. Connect the Roller Shutter in accordance with the wiring diagram presented on Fig. 1 (roller blinds, venetian blinds) or Fig. 2 (gates).
- 3. Place the device in a switch hox
- . Arrange the antenna (tips presented below Fig. 3) 5. Turn on the power supply keeping the necessary safety
- precautions.

  6. Include the module into the Z-Wave network, observing pt. VI
- 7. If necessary, calibrate the module, observing pt. IX descripion





Fig. 1 Roller Shutter wiring diagram



#### NOTES FOR THE DIAGRAM: - terminal for live lead

- \$1 terminal for key no. 1 (has the option of entering the device in
  - S2 terminal for key No. 2
  - Q1 output terminal no. 1 for shutter motor
  - Q2 output terminal no. 2 for shutter motor
  - B service button (used to add or remove a device from the




Fig.3 Installation of Fibaro Roller Shutter in wall switch box.



# CALITION

The device is designed for installation in wall switch boxes and can work only with the electrical connectors compliant with the relevant safety



## CAUTION

The switch box must be compliant with the relevant national safety standards and its depth should not be less than 60mm.



# WADNING


Fibaro Roller Shutter is dedicated to operate with AC powered electric motors. Connecting the device directly to DC powered motors may result in them being damaged.





It is recomended to monitor regulary operation of Fibaro Roller shutter in all modes. In case of gate control mode device, motor limit switches, infrared barriers and emergency stop should be monitored

# NOTE



### TIPS FOR ARRANGING THE ANTENNA

- 1. Locate the antenna as far from metal elements as possible (connection wires, bracket rings, etc.) in order to prevent interferences.
- 2. Metal surfaces in direct vicinity of the antenna (e.g. metal switch boxes, door frames) may impair radio signal reception
- 3. Do not cut or shorten the antenna. Its length is perfectly matched to the band in which the system operates.

### VI. Z-WAVE NETWORK INCLUSION

Fibaro Roller Shutter may be included into the Z-Wave network via the B-button or a push button connected to the S1 terminal. In addition, the module may be included in auto inclusion mode, by simply connecting the power supply.

Automatic Z-Wave network inclusion:

- Make sure the power supply is disconnected end a Roller Shutter is located within a direct Z-Wave network's main controller communication range.
- 2) Set the main controller into the learn mode (see main controllers operating manual).
- 3) Connect the power supply to include the Roller Shutter in auto
- 4) Fibaro Roller Shutter will be automatically detected and included into the 7-Wave network
- To disable the auto inclusion mode, press the B-button briefly, after connecting the module to the power supply.
- Manual Z-Wave network inclusion:
- 1) Connect the power supply.
- 2) Set the main controller into the learn mode (see main controllers operating manual).
- 3) Triple click the B-button or a push button connected to the S1
- 4) Fibaro Roller Shutter will be detected and included into the 7-Wave network.

## VII. Z-WAVE NETWORK EXCLUSION

- 1) Make sure the module is connected to the power supply.
- 2) Set the main controller into the learn mode (see main controllers
- 3) Triple click the B-button or a push button connected to the S1

### VIII. ROLLER SHUTTER RESET

Reset procedure clears the modules' EPROM memory, including all information about the Z-Wave network controller, calibration and

- 1) Make sure the module is connected to the power supply.
- 2) Press and hold the B-button for ca. 14 seconds.
- 3) LED indicator will glow yellow.
- 4) Release the B-button and press it again, briefly 5) The Roller Shutter memory is now empty.
- 6) The module goes into the auto inclusion mode, until any button is pushed.



# CAUTION

Memory reset does not remove the module from the Z-Wave network main controller's memory. Prior to memory reset it's recommended to exclude the module from the Z-Wave network.



After memory reset, the Roller Shutter goes into the auto inclusion mode and waits to be included into the Z-Wave network. To exit the auto inclusior mode press the B-button briefly.

# IX. POSITIONING CALIBRATION

Calibration is a process during which a Roller Shutter learns the position of the limit switches and a motor characteristic. Calibration is mandatory in order for the Roller Shutter to correctly recognize a roller blind position. The procedure consists of an automatic, full movement between the limit switches (up, down, and up again). There are separate procedures of calibrating roller blind and slats (venetian blind) positioning. Each time the calibration requires the completion of a full cycle (up and down).

## **ROLLER BLIND POSITIONING CALIBRATION**

There are 5 procedures of calibrating a Fibaro Roller Shutter to choose from. Each one gives the same results and the user may choose which one to execute.

- A. Calibration through a Fibaro Home Center 2 interface
- Make sure the module is connected to the power supply, according to Fig.1
- 2) Include the module into the Z-Wave network, according to section VI of instructions.
- 3) In Home Center 2 interface choose Fibaro Roller Shutter's
- advanced settings.

  4) Click CALIBRATE buttin in the devices advanced settings tab.
- Noller Shutter performs the calibration process, completing full cycle up, down and up again.
   Using an interface test whether the positioning works correctly.
- B. Calibration through the Z-Wave network
- 1) Make sure the module is connected to the power supply. according to Fig.1
- 2) Include the module into the Z-Wave network, according to section VI of instructions
- 3) Set the parameter 29 value to 1. 4) Roller Shutter performs the calibration process, completing full
- cycle up, down and up again.

  5) The parameter 29 value will be automatically set to 0.
- 6) Using an interface test whether the positioning works correctly.
- C. Calibration through the switch keys
- 1) Make sure the module is connected to the power supply. according to Fig.1, and to the switch keys as well (S1 and S2
- 2) Include the module into the Z-Wave network, according to section VI of instructions.

  3) Press and hold the switch key connected to S1 or S2 input
- nat and release it after at least 3 seconds. 4) Press and hold the same switch key again, and release it after 3
- 5) Now press and hold the same button, for 3 seconds, for the 3rd
- 6) After pressing and releasing the button for the third time.
- automatic calibration sequence will start.

  7) Roller Shutter performs the calibration process, completing full cycle - up, down and up again.
- D. Calibration through Menu (B-button)
- 1) Make sure the module is connected to the power supply, according to Fig.1
- 2) Include the module into the Z-Wave network, according to section
- 3) Press and hold the B-button for ca. 6 seconds.
- 5) Release the B-button and press it again, briefly. 6) Roller Shutter performs the calibration process, completing full
- E. Calibration through a Fibar Command Class control frame. It's possible to force the calibration process execution through sending a Fibar Command Class control frame through a Z-Wave



cycle - up, down and up again.

To abort the calibration process press any key (connected to S1 or S2) or send a STOP control frame through the Z-Wave network controller. In Gate Controller mode the calibration process will be aborted after disconnecting the S2 terminal.

# CALIBRATING SLATS POSITIONING IN VENETIAN BLINDS

Apart from calibrating the roller blind position, it's possible to calibrate the position of venetian blinds slats. After correct catibration, in case of venetian blinds, it's possible to set the position between the limit switches, as well as the slats angle. By default, time of full turn of the slats is set to 1,5 seconds. If necessary, it can

- ne modified following below instructions 1) Make sure the module is connected to the power supply,
- according to Fig.1 2) Include the module into the Z-Wave network, according to saction
- VI of instructions.

  3) Calibrate the Roller Shutter, according to the instructions provided in sections IX.A, IX.B, IX.C, IX.D or IX.E. 4) Set the parameter 10 value to 2 or choose in HC2 interface
- Device Type Venetian Blind Another device icon, responsible for slats operation, will show up in Home Center 2 interface. In case of any other Z-Wave network controllers managing the slats position is achieved through pressing and holding a switch key (up or down).
- 6) By default, time of transition between extreme positions is set to 1 500 ms (1,5 seconds).

  7) Turn slats between extreme positions. If after full cycle a blind starts moving up or down, then parameter's 12 value must be modified, e.g. to 1 000ms (1 second). Correctly configured

slats should not force the blind to move up or down.



CAUTION Roller Shutter needs to be calibrated to work with

CAUTION In Venatian Blind mode, slats need to be calibrated to work with any given motor.

any given motor.



### Venetian blind slats may be only operated by momentary switches.

#### X. OPERATING THROUGH THE Z-WAVE NETWORK

After including into the Z-Wave network, Fibaro Roller Shutter will be presented in a Home Center 2 interface as a roller blind icon (see fig. below) After choosing Venetian Blind device type, a second icon






Fig. 4 Roller Shutter icons in Home Center Interface


Liser can choose from the following operating modes

- 1. Roller Blind Mode, without positioning
- 2. Roller Blind Mode, with positioning 3. Venetian Blind Mode
- Gate Mode, without positioning 5. Gate Mode, with positioning

0; parameter 17 set to 0)

After choosing one of the above operating modes, device will be represented in Home Center 2 interface by icons shown in Fig.4. In addition, each operating mode affects certain parameters settings:

- 1) Roller blind without positioning (parameter 10 set to 0)
- 2) Roller blind with positioning (parameter 10 set to 1)
  3) Venetian blind (parameter 10 set to 2; parameter 13, set to 2)
  4) Gate without positioning (parameter 10 set to 3; parameter 12 set
- to 0: parameter 17 set to 0) 5) Gate with positioning (parameter 10 set to 4; parameter 12 set to



Above operating modes and their default settings are modified automatically only in Home Center 2 controller. In case of the Z-Wave network controllers from other manufacturers, these settings need to be manually adjusted (see section

Opening / Closing a blind is acheved through moving a slider or

pushing a button shown in Fig. 4. In Venetian Blind mode, setting slats angle is achieved through moving a slider or pushing a button shown in Fig. 4.

## XI. MANUAL OPERATION

Fibers Roller Shutter allows for connecting push buttons to S1 and S2 terminals. These may be momentary or toggle switches atternatively. Push buttons are responsible for managing the blind's

Using momentary switches: Clicking A button connected to S1 terminal, initiates up

Clicking ▼ button connected to S2 terminal, initiates down If the blind is moving, each click, of any button, will stop the movement. In addition a button click sends a command frame to 1-st

association group devices. in case of venetian blinds, it's possible to manage the slats angle. Operating Mode - Venetian Blind, or Parameter 10 value set to 2. **Holding** ▲ connected to S1 terminal initiates slats rotation up.

Holding ▼ connected to S2 terminal initiates slats rotation down. in addition a button hold sends a Fibar Command Class control frame to II-nd association group devices

movement

Using toggle switches: Changing A switch key position, connected to S1 terminal,

Changing witch key position, connected to S2 terminal, initiates down movement. Choosing a middle position stops the blind.

Through an association Fibaro Roller Shutter may control another Z-Wave network device, e.g. another Roller Shutter, Wall Plug, Dimmer, Relay Switch, RGBW Controller.



# Association allows for direct communication

between Z-Wave network devices. Main controller does not take part in such communication

Fibaro Roller Shutter provides three association groups:

I association group is triggered through a momentary switch click or a toggle switch position change.

Il association group is triggered through a momentary switch hold



#### NOTE

Il association group is inactive when toggle switches are used or in Gate Controller mode (parameter 10). In case of controlling Venetian Blinds, control commands are sent in Fiber Command Class

Ill association group reports the module status. Only one device may be assigned to this group, main controller by default. It's not

recommended to modify this group's settings.
Fibaro Roller Shutter allows for commanding other Roller Shutters, associated into I or II association group, through clicking or holding a switch key. For example, this mechanism allows for operating a Roller Shutter connected to the switch with a button click, and operating the devices associated in II association group by a button hold. In addition, when operating Venetian Blinds, it's possible to

#### USING ASSOCIATIONS TO OPERATE ANOTHER ROLLER SHUTTER OR ANY OTHER Z-WAVE DEVICE.

#### LASSOCIATION GROUP:

Clicking button, connected to S1 terminal will initiate up movement in associated Roller Shutters, or send Turn On command frame to the devices associated in I-st association group.

Clicking ▼ button, connected to S2 terminal will initiate down movement in associated Roller Shutters, or send Turn Off command frame to the devices associated in I-st association group.

#### II ASSOCIATION GROUP:

Holding **A** button, connected to S1 terminal will move the connected roller blind up, and after 1 second delay initiate up movement in associated Roller Shutters, or send Tum On command frame to the devices associated in II-nd association group.

Iding | button, connected to S2 terminal will move the conected rolled blind down, and after 1 second delay initiate down vement in associated Roller Shutters, or send Turn Off command

#### USING ASSOCIATIONS TO OPERATE ROLLER SHUTTERS CONNECTED TO VENETIAN BLINDS.

Using association mechanism to operating venetian blinds requires configuring both. I-st and II-nd association groups.

## LASSOCIATION GROUP

Clicking A button, connected to S1 terminal will initiate up movement of the connected venetian blind and other devices associated in I-st association group.

Clicking ▼ button, connected to S2 terminal will initiate down movement of the connected venetian blind and other devices associated in I-st association group.

II ASSOCIATION GROUP (relevant for momentary switches only) Holding button, connected to S1 terminal will initiate slats rotation up, of the connected venetian blind as well as the other devices associated in II-nd association group.

Holding button, connected to S2 terminal will initiate slats

rotation down, of the connected venetian blind as well as the other devices associated in II-nd association group.



Once the associated devices are already moving, they will be stopped if any of the buttons is pressed and held.

### XIII. OPERATING GATE MOTORS

Fibaro Roller Shutter allows for operating gate motors. Gata motor should be connected to Q1 and Q2 terminals according to Fig.2. In the Gate Mode, a momentary switch may be connected to S1 terminal. It's recommended to connect an IR barrier, an emergency stop button or any alarm mechanism to S2 terminal. Opening a contact in a device connected to \$2 terminal will always result in stopping a motor in current position (see Fig. 2).

Clicking a push button connected to S1 terminal will initiate opening the gate. Next click of a button will stop the gate. Yet another click of a button will close the gate. According to following seaquence:  $OPEN \rightarrow STOP \rightarrow CLOSE \rightarrow STOP \rightarrow OPEN$ .



Fig. 5 Roller Shutter icon in Home Center interface



In Gate Mode, by default, the S1 terminal is set to operate with a momentary switch, ignoring the parameter 14 settings.

Full opening the gate initiates a Roller Shutter COUNTDOWN. After the COUNTDOWN the gate will start closing. COUNTDOWN length is set through the parameter 12. In addition, if the IR harrier is cut (\$2 contact opened) at the gate fully open, the gate will start closing after a time period specified in parameter 17



In both Gate Modes, with and without positioning parameters 12 and 17 are automatically set to 0. At these settings the gate will open, but will not automatically close. Relevant times need to be set nually in parameters 12 and 17 (see section XVIII).



#### NOTE

Parameters 12 and 17 settings are automatically modified only in Home Center 2 controller, when choosing one of Gate Modes. In case of controllers from other manufacturers these parameters need to he set manually (see section XVIII)

Installation of the gate driver may be performed only by certified professionals. The motor must be equipped with the appropriate limit switches (see Fig. It's recommended to connect a NC (normall closed) contact of an IR barrier to S2 termina Opening the contact will stop the gate. In addition, it's recommened to connect an emergency stop button to the motors neutral (N) wire. In emergency, pushing the emergency stop button will cut the power and stop the gate. It is recomended to monitor regulary operation of Fibaro Roller shutter in all modes. Also it is recomended to regulary verificate



S1 and S2 terminals react to mains voltage only. Using iR barriers with NC contacts operating on lower voltages require using an additional relay (see Fig. 2)

#### XIV. LED INDICATOR

Fibaro Roller Shutter has a MENU Each MENU level is signaled through a LED Indicator colour, To enter MENU press and hold the B-button for at least 2 seconds.

While the B-button is being held, LED Indicator colours will change

BLUE - Roller Shutter calibration procedure (see section IX) VIOLET - initiate the Z-Wave network range tester

GREEN - reset energy consumption data memory (see section XVI)
YELLOW - Roller Shutter reset (see section VIII) Release the B-button to choose the desired function and confirm your choice with the B-hutton click

## XV. Z-WAVE RANGE TESTER

Fibaro Roller Shutter has a built in mechanism, allowing to roughly estimate the Z-Wave network range



To allow for the 7-Wave network renne test the Z-Wave network controller needs to support the functionality and the module needs to be included in the network. Z-Wave range test puts heavy strain on the network, so it's recommended to use the function only in special cases

In order to test the Z-Wave network range:

1) Press and hold the B-button for ca. 6 seconds, until the LED Indicator glows violet

2) Release the B-button

3) Click the B-button.

4) LED Indicator will signal the Z-Wave network range (see description below).

5) Click the B-button to exit the Range Tester

Network range signaling modes:

Z-Wave network range is signaled by LED illumination colour and behaviour. Blinking each 1-second means the modules tries to establish a direct communication with the main controller while 2 wing means the test result. The test is performed in loop, until being stopped by the user. Z-Wave range test is performed in three steps, signaled with green, yellow, violet and

1) Blinking in GREEN means the module tries to establish a direct communication with the main controller. Positive test result is signaled by a 2 second glowing in GREEN, after which the test is repeated (step 1). In practice, if the module is able to establish a direct communication with the main controller, the LED will glow GREEN, without blinking.

2) If the module is not able to establish a direct connection with the main controller, it will try to establish a routed connection, through another, intermediary, Z-Wave network devices. LED indicator will change the illumination colour to RFD. Positive test result is signaled with glowing in YELLOW. After 2 seconds the module will retry establishing a direct communication (step 1).



The module may modify the main controller communication from direct to routed and vice versa, especially if it's located at the direct communication range limit.

3) If the module is not able to establish a routed connection with the main controller, LED Indicator colour will change from YELLOW to VIOLET. After few seconds test will end and the LED Indicator will glow RED for two seconds. Whole procedure will start again and the module will try to establish a direct connection with the controller (step 1).

#### XVI. CURRENT AND HISTORICAL POWER CONSUMPTION MEASURING

Fibaro Roller Shutter allows for the current load and power consumption monitoring. Data is sent to the main controller, e.g. Home Center 2

Measuring is carried out by an independent microproces dedicated exclusively for the purpose, assuring maximum accuracy and precision. The microprocessor is factory calibrated.

Electric power - power consumed by an electric device in an instant in Watts (W),

Electric energy - energy consumed by a device through a time period. Most commonly measured in kilowatt-hours (kWh). One kilowatt-hour is equal to one kilowatt of power consumed over a period of one hour 1kWh = 1000 Wh

### RESETTING FLECTRICITY CONSUMPTION MEMORY

Fiharo Roller Shutters electricity consumption memory may be cleared in one of the following ways:

- 1) Through the module reset (see section VIII)
- 2) Through the main controller menu (see main controllers operating manual
- 3) Manually using the following instructions:
- A) Make sure the device is connected to voltage supply.
   b) Press and hold the B-button for ca. 10 seconds, until LED I
- ndicator glows GREEN.
  Release the B-button.
- d) Click the B-button.

e) Energy consumption memory has been erased.



Please contact your local supplier for the current

2) Fibaro Roller Shutter stores consumed electricity data on its memory, which means disconnecting the module from voltage supply does not erase the

### XVII. PROTECTION MODE

Fibaro Roller Shutter uses the Protection Command Class v2 to 1) Local Protection

- Local Protection State:
- 0 no protection. Roller Shutter responds to push huttons - not supported 2 - Local protection active. Roller Shutter does not respond to

Once the Local Protection is activated, the module stops responding to S1 and S2 push buttons, SCENE ID and association commands will not be sent as well. The only exception is the B-button. Menu and Z-Wave network inclusion, after the B-button



### WARNING

or S1 nush button triple click, are still active.

In Protection Mode it will not be possible to control Fibaro Roller Shutter from buttons. It is not recomended to control all Fibaro Roller Shutters in



# CAUTION

There's one more exception in Local Protection, in Gate Mode, S2 (IR Barrier) is still active. It means if the obstacle is detected, the gate will stop, regardless the Local Protection State set.

# 2) RF Protection (radio protection)

RF Protection State:

0 – No protection. Roller Shutter responds to command frames.

- 1 RF Protection active. Roller Shutter does not respond to the Z-Wave control frames.
- 2 not supported.

Once the RF Protection is activated, the module stops responding to command frames setting the blind position. It's still possible however to configure the device (advanced configuration parameters, protection modes) and checking it's current state rough polling (position, power, energy).


## XVIII. ADVANCED CONFIGURATION

# GENERAL SETTINGS:

3. Reports type

- 0 Blind position reports sent to the main controller using Z-Wave Command Class. 1 - Blind position reports sent to the main controller using Fiber
- Parameters value shoud be set to 1 if the module operates in Venetian Blind mode

Default setting: 0 Parameter size: 1 [byte]



#### 10. Roller Shutter operating modes:

- 0 Roller Blind Mode, without positioning
- Roller Blind Mode, with positioning
- 2 Venetian Blind Mode with positioning
- 4 Gate Mode, with positioning

#### Default settng: 1

Parameter size: 1 [byte]

12. In Venetian Blind mode (parameter 10 set to 2) the parameter determines time of full turn of the slats.

In Gate Mode (parameter 10 set to 3 or 4) the parameter defines the COUNTDOWN time, i.e. the time period after which an open gate starts closing. In any other operating mode the parameter value is

Value of 0 means the gate will not close automatically. Available settings: 0-65535 (0 - 655 35s)

Default setting: 150 (1,5 s) Parameter size: 2 [bytes]

#### 13. Set slats back to previous position.

In Venetian Blind Mode (parameter 10 set to 2) the parameter influences slats positioning in various situations. In any other operating mode the parameter value is irrelevant.

- 0 Slats return to previously set position only in case of the main controller operation.

  1 - Slats return to previously set position in case of the main
- controller operation, momentary switch operation, or when the
- 2 Slats return to previously set position in case of the main controller operation, momentary switch operation, when the limit switch is reached or after receiving a "STOP" control frame (Switch Multilevel Stop)

Default setting: 1 Parameter size: 1 [bvte]

# 14. Switch type.

The parameter settings are relevant for Roller Blind Mode and Venetian Blind Mode (parameter 10 set to 0, 1, 2).

- 0 Momentary switches
- 1 Toggle switches ngle, momentary switch. (The switch should be connected to
- S1 terminal)

Default setting: 0 Parameter size: 1 [byte]

# 17. In Roller Blind Mode or Venetian Blind mode (parameter 10 set to 0, 1, 2) the parameter determines when the Roller Shutter relays are turned off after reaching a limit switch.

In Gate Mode (paremeter 10 set to 3 or 4) the parameter dete a time period after which a gate will start closing after a S2 contact has been disconnected. In this mode, time to turn off the Roller Shutter relays after reaching a limit switch is set to 3 seconds and cannot be modified

Value of 0 means the gate will note close automatically.

Available settings: 0 - 255 (0,1-25,5s). Default setting: 10 (1s).

# rameter size: 1 [byte]

18. Motor operation detection.

Power threshold to be interpreted as reaching a limit switch. Available settings: 0 - 255 (1-255 W)

The value of 0 means reaching a limit switch will not be dete Default setting: 10 (10W).

# 22. Motor operation time.

Time period for the motor to continue operation.

Available settings: 0 - 65535 (0 - 65535s) The value of 0 means the function is disabled

#### Default setting: 240 (240s. – 4 minutes) Parameter size: 2 [bytes] 29. Forced Roller Shutter calibration

By modifying the parameters setting from 0 to 1 a Roller Shutter enters the calibration mode. The parameter relevant only if a Roller Shutter is set to work in positioning mode (perameter 10 set to 1, 2

1 - Start calibration process Default setting: 0 Parameter size: 1 [byte]

# ALARM SETTINGS:

30. Response to general alarm

- 1 Open blind. 2 - Close blind
- Default setting: 2
- Parameter size: 1 [byte] 31. Response to flooding alarm
- 0 No reaction - Open blind 2 - Close blind.

Default setting: 0 Parameter size: 1 [byte]

32. Response to smoke, CO or CO2 alarm

0 - No reaction. 1 - Open blind. 2 - Close blind.

Default setting: 1 Parameter size: 1 [byte] 33. Response to temperature alarm

- 0 No reaction
- Open blind
- 2 Close blind. Default setting: 1

Parameter size: 1 [byte]

35. Managing slats in response to alarm. In Venetian Blind Mode (parameter 10 set to 2), the parameter determines how the slats will react upon alarm detection. In any other modes, the parameter value is not relevant.

- 0 Do not change slats position slats return to the last set
- 1 Set slats to their extreme position.

Default setting: 1 Parameter size: 1 [hvte]

## POWER AND ENERGY REPORTS SETTINGS:

#### 40 Power reports.

Power level change that will result in new power value report being sent. The parameter defines a change that needs to occur in order to trigger the report. The value is a percentage of the previous report.

Power report threshold available settings: 1-100 (1-100%).

Value of 0 means the reports are turned off.

Default setting: 10 (10%) Parameter size: 1 [byte]

# 42. Periodic power or energy reports.

The parameter defines a time period between consecutive reports.

Available settings: 1-65534 (1-65534 seconds) Value of 0 means the reports are turned off

Default setting: 3600 (3600 seconds / 60 minutes).

Parameter size: 2 [bytes] 43. Energy reports.

Energy level change which will result in new energy value report being sent. The paremeter defines a change that needs to occur in order to trigger the report.

Energy threshold available settings: 1-254 (0.01 - 2.54kWh) Value of 0 means the reports are turned of

#### Default setting 10 (0.1kWh). Parameter size: 1 [byte]

44. Self-meesurement. A Roller Shutter may include power and energy used by itself in

reports sent to the main controller. 0 - Self-measurement inactive.

1 - Self-measurement active Default setting: 0 Parameter size: 1 [byte]

# SCENES AND ASSOCIATIONS SETTINGS:

50. Scenes / Associations activation. Parameter determines whether scenes or associations are activated

by the switch keys. 0 - Associations activation

1 - Scenes activation Default setting: 0

# Parameter size: 1 [byte] YIY GUARANTEE

- 1. The Guarantee is provided by FIBAR GROUP S.A. (hereinafter 'Manufacturer"), based in Poznan, ul. Lotnicza 1; 60-421 Poznan, entered in the register of the National Court Register kept by the District Court in Poznań, VIII Economic Department of the National Court Register, no. 553265, NIP 7811858097, REGON:
- 2. The Manufacturer is responsible for equipment malfunction resulting from physical defects (manufacturing or material) of the Device for 12 months from the date of its purchasing.
- 3. During the Guarantee period, the Manufacturer shall remove any defects, free of charge, by repaining or replacing (at the sole discretion of the Manufacturer) any defective components of the Device with new or regenerated components that are free of defects. When the repair impossible, the Manufacturer reserves the right to replace the device with a new or regenerated one, which shall be free of any defects and its condition shall not be worse than
- the original device owned by the Customer. 4. In special cases, when the device cannot be replaced with the device of the same type (e.g. the device is no longer available in the commercial offer), the Manufacturer may replace it with a different device having technical parameters similar to the faulty one. Such activity shall be considered as fulfilling the obligations of the Manufacturer. The Manufacturer shall not refund money paid for the device.
- 5. The holder of a valid quarantee shall submit a quarantee claim through the guarantee service. Remember: before you submit a guarantee claim, contact our technical support using telephone or e-mail. More than 50% of operational problems is resolved remotely, saving time and money spent to initiating guarantee procedure. If remote support is insufficient, the Customer shall fill the guarantee claim form (using our website - www.fibaro.com) in order to obtain claim authorization. When the guarantee claim form is submitted correctly, the Customer shall receive the claim confirmation with a unique number (Return Merchandise Authorization -RMA).
- 6. The claim may be also submitted by telephone. In this case, the call is recorded and the Customer shall be informed about it by a consultant before submitting the claim. Immediately after submitting the claim, the consultant shall provide the Customer with the claim number (RMA-number).
- 7. When the guarantee claim form is submitted correctly, a resentative of the Authorised Guarantee Service (hereinafter as "AGS") shall contact the Customer.

8. Defects revealed within the guarantee period shall be removed not later than 30 days from the date of delivering the Device to AGS. The guarantee period shall be extended by the time in which the Device was kept by AGS.

- 9. The faulty device shall be provided by the Customer with complete standard equipment and documents proving its
- 10. Parts replaced under the guarantee are the property of the Manufacturer. The guarantee for all parts replaced in the guarantee process shall be equal to the guarantee period of the original device. The guarantee period of the replaced part shall not be
- . Costs of delivering the faulty device shall be borne by the Customer. For unjustified service calls, the Service may charge the Customer with travel expenses and handling costs related to the
- 12. AGS shall not accept a complaint claim only when:
- the Device was misused or the manual was not observed. · the Device was provided by the Customer incomplete, without
- · it was determined that the fault was caused by other reasons than a material or manufacturing defect of the Device
- · the guarantee document is not valid or there is no proof of
- 13. The Manufacturer shall not be liable for damages to property caused by defective device. The Manufacturer shall not be liable for indirect, incidental, special, consequential or punitive damages, or for any damages, including, inter alia, loss of profits, savings, date, loss of benefits, claims by third parties and any property damage or personal injuries arising from or related to the use of the Device

mechanical damages (cracks, fractures, cuts, abrasions, physical

deformations caused by impact, falling or dropping the device or other object, improper use or not observing the operating manual); damages resulting from external causes, e.g.: flood, storm, fire, lightning, natural disasters, earthquakes, war, civil disturbance,

14. The guarantee shall not cover:

leakage, battery spill, weather conditions, sunlight, sand, moisture, high or low temperature, air pollution: damages caused by malfunctioning software, attack of a computer virus, or by failure to update the software as recommen-

force majeure, unforeseen accidents, theft, water damage, liquid

- · damages resulting from: surges in the power and/or talecommunication network, improper connection to the gnd in a manner inconsistent with the operating manual, or from connecting other devices not recommended by the Manufacturer · damages caused by operating or storing the device in extremely
- operating the Device are defined in the operating manual: · damages caused by using accessories not recommended by the

adverse conditions, i.e. high humidity, dust, too low (freezing) or too high ambient temperature. Detailed permissible conditions for

- damanes caused by faulty electrical installation of the Customer including the use of incorrect fuses; · damages caused by Customer's failure to provide maintenance
- and servicing activities defined in the operating manual;
- · damages resulting from the use of spurious spare parts or accessories improper for given model, repairing and introducing
- alterations by unauthorized persons: defects caused by operating faulty Device or accessories 15. The scope of the guarantee repairs shall not include periodic maintenance and inspections, in particular cleaning, adjustments, operational checks, correction of errors or parameter programming and other activities that should be performed by the user (Buyer).
- The guarantee shall not cover natural wear and tear of the Device and its components listed in the operating manual and in technical documentation as such elements have a defined operational life. 16. If a defect is not covered by the guarantee, the Manufacturer reserves the right to remove such defect at its sole discretion, repaining the damaged or destroyed parts or providing components
- necessary for repair or replacement. 17. This guarantee shall not exclude, limit or suspend the Customer rights when the provided product is inconsistent with the purchase

other manufacturers.



Any device compatible with Z-Wave may be added to Fibaro system.

Hereby, Fibar Group S.A. declares that this Fibaro Roller Shutter 2 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC.

This Device may be used with all devices

certified with Z-Wave certificate and should be compatible with such devices produced by

# **FIBARGROUP**

In case of any technical questions contact customer service centre

www.flbaro.com

**FIBARO**